
# L60H, L70H, L90H

Volvo Wheel Loaders 11.0-17.3 t 167-186 hp



# WELCOME TO OUR WORLD

Welcome to a world of industry leading machinery. A world where imagination, hard work and technological innovation will lead the way towards developing a future which is cleaner, smarter, and more connected. A world supported by the enduring values of the Volvo Group. A world of stability, sustainability and innovation. A world which we put our customers at the heart of.

Welcome to the world of Volvo Construction Equipment – we think you're going to like it here.

# Working harder, working smarter

For over 180 years Volvo has been a pioneer in the design and manufacture of machines which set the standard for efficiency, performance and uptime. Across our range of excavators, wheel loaders and haulers, our reputation for engineering excellence is unrivalled, which means whatever your operation or application, we can provide a total fleet solution to help you succeed.

Building on our proud history, the Volvo Concept Lab continues to create cutting-edge ideas and innovative concepts, to ensure we offer customers machines which work harder and smarter long into the future.



# Solutions for you

Our industry leading machines are just the start of your relationship with Volvo. As your partner, we have developed an extensive range of additional solutions to help you improve uptime, boost productivity and reduce costs.

### Designed for your business

Structured across nine blocks, our portfolio of products and services are designed to complement your machine's performance and boost your profitability. Simply put, we offer some of the best guarantees, warranties and technological solutions in the industry today.

# There when you need us

Whether you're buying new or used, our global network of dealers and technicians offer around-the-clock support, including machine monitoring and world-class parts availability. It's the basis of everything offered by Volvo Services, so you can be confident we've got you covered right from the start.

**BUILDING TOMORROW** 

# Multitude of talents

Say hello to the latest additions to the H-Series wheel loaders: the upgraded L60H, L70H and L90H. Built on the established H-Series design, the next-generation machines are the ultimate all-rounders, offering the high quality performance you'd expect from a Volvo wheel loader, plus a host of features that promote greater versatility and stability to handle your workload.

### Designed to do more

Knock heavy-duty jobs down to size with the H-Series wheel loaders. These robust workhorses offer unshakable stability thanks to the new, optimized loading unit weight and redesigned counterweight. Designed to do more, the well-balanced machines yield up to 3% higher tipping load, so you can tackle a variety of tasks — no matter how demanding.




# Adapt to any application

Get the most out of your machine with a range of purpose-built attachments, including grapples, sweepers, material handling arms, snow ploughs and more. Because different jobs require different attachments, we can custom build a Volvo attachment to match your specific needs. To unlock the use of multiple attachments, simply engage the third and fourth hydraulic functions.



# **Fully loaded**

Whatever the job, we have the tools to get it done. Volvo offers a full range of Volvo buckets, including general purpose, grading, refuse, light material, and more, to handle everything, from light material to heavy rocks. Built on decades of engineering excellence, Volvo buckets are optimized for Volvo wheel loaders and durably designed for all types of materials and tasks.



# Made to match

Lift your machine's versatility to the next level with pallet forks, offering high visibility and the advantage of TP linkage and parallel movement. Ideal for pallet and material handling, Volvo forks are heavy-duty in design, allowing the wheel loader to move effortlessly around different work sites, such as yards, warehouses and harbors.



# LOADED WITH VERSATILITY

Take on any application with the H-Series wheel loaders, equipped with the Torque Parallel (TP) linkage for ultimate versatility. Not only does the TP linkage offer high breakout, tilt in and lifting forces, it keeps the attachments parallel throughout the lifting range for exceptional load stability and easy bucket filling. Change tools in a matter of seconds with the Volvo attachment bracket.






L90H: put to the test

"Even when the machine was fully turned, it remained stable and showed no indication of tipping over."

Test driver Sebastian Alm, Firma Sebastian Alm (Sweden)

# UP TO 20% MORE EFFICIENT

Achieve up to 20% greater fuel efficiency thanks to advanced features, such as Eco pedal and the new optional lock-up function. The lock-up feature eliminates losses in the torque converter by creating a direct drive between the engine and transmission, which work in harmony with the axles. To improve cycle times and fuel use, customize the lock-up engagement of your machine.



# Drive down your costs

Get the most out of your investment with a cost-effective solution. At Volvo, we're committed to driving your operating costs down. That's why we've refined the mid-sized H-Series wheel loaders to deliver up to 20% greater fuel efficiency and optimize productivity.

### Productivity up, fuel down

Cut operating costs and propel your machine's productivity with rimpull control. With the power to control the rimpull, the operator can reduce tire wear and prevent wheel spin for effective bucket filling. Select the optimum rimpull to match the application and ground conditions, and experience high productivity at low costs.

### Work smarter

For the best use of engine power in all applications, rely on Smart Control, designed to optimize fuel efficiency and performance. Standard on the mid-sized H-Series wheel loaders, Smart Control ensures the correct torque in all situations for perfect harmony between the engine and



### Do more on and off road

Do more on and off road with an increased top speed of 50km/h. Not only is the machine faster, it is also a pleasure to operate thanks to the optional lock-up feature, which improves drive response and incline performance.



### Boost your profitability

Ensure a low total cost of ownership with a host of Productivity Services and Fuel Efficiency Services. From reports, training packages and consultancy solutions, Volvo has you covered – just speak to your dealer for more information.



# Comfortably in control

It's not just the machine that's ready for any challenge. From the comfort and security of the spacious Volvo cab, the operator is primed for a productive work shift.

# Safety as standard

Safe from the inside out, the latest loaders feature anti-slip steps and strategically placed handrails for ease of access, plus an array of seatbelt options, such as the orange three-point seatbelt. The new attachment bracket uses a visual indicator to let you know the attachment is locked and ready to use.



# See more, do more

Experience a clear view of the attachment and jobsite thanks to large expanses of glass, redesigned side mirrors, rear-view camera and optional front camera. The machines also feature orange handrails and steps to stand out against the jobsite, and LED lights, available in various packages.



# Take command

Customize your Volvo and take command of hydraulic functions with the optional electro servo controls. From the cab, adjust the detent third function, boom kick-out, return to dig and bucket leveling. Easily change between linear or single lever controls and select from three hydraulic settings to tailor the lever control according to your preferences.



# **Bucket leveling function**

Take your productivity to the next level with the bucket leveling function, available when you select the optional electro hydraulic lever. The new function enhances operator performance by automatically returning the bucket from both dump and curl positions.



# NO COMPROMISE ON COMFORT

Hard work has never felt so easy from the spacious of the Volvo cab, featuring your choice of comfortable operator seat, as well as ergonomic controls. Perform basic configurations using the information panel, and keep an eye on the operation with the Contronic display.





# L90H: put to the test

"Everything is thought through and logical."


Test driver Sebastian Alm, Firma Sebastian Alm (Sweden)

"In comparison to many other machines, I thought it was very quiet and comfortable inside the cab."

Test driver Mattias Wallin, Mattias Wallin AB (Sweden)

# OPERATOR COACHING

As machines become more advanced, and with smarter technology, the Operator Coaching app helps to ensure operators are using their Volvo machine to its full potential. The intuitive app provides real-time guidance to operators, helping them understand how their actions influence machine productivity and efficiency, as well as identify areas for improvement or changes in their technique.





# Operator Coaching app: put to the test

"I find it really useful. The system will tell me when to activate the Boom Suspension System, when to activate Lock-Up and flag up any changes I need to make to my operating style, like not riding the brakes and the throttle at the same time."

Operator from USA

# **Load Assist**

Optimize your load cycles with Load Assist, powered by Volvo Co-Pilot – the revolutionary in-cab display. Gain access to a set of smart apps\* and boost the efficiency of your operation.

\*The On-Board Weighing app is not available on L60H, L70H and L90H.

# Мар

Get accurate machine positioning with Map, a clever app that allows operators to monitor on-site traffic in real-time. Not only does this give operators an improved orientation of the site they are working on, but it allows them to proactively adjust their driving behavior according to traffic conditions.



### Integrated rear-view

Operators benefit from a full view of their surroundings when reversing, thanks to the optional rear-view camera and radar detect system which are now integrated into the Volvo Co-Pilot display.



### Calculator

Complete basic calculation and use the Calculator app to quickly and easily convert six unit types (length, mass, angle, time, temperature and speed).

### Notes

There's no need for a pad and pen with the Notes app. The digital notepad can be used to write and save notes while in the cab.

### Weather

Stay on top of the weather with the easy-to-view Weather app, helping you stay informed of current and upcoming weather conditions.



# **Ultimate all-rounder**

## Designed to do more

- Optimized loading unit weight, heavy-duty counterweight for greater stability
- $\bullet$  Higher tipping load 1.7% for L60H, 1.6% for L70H, 3% for L90H
- L90H: increased lifting height by 73mm
- Optional electro-servo controls
- Bucket leveling function

# **LOADED WITH VERSATILITY**

- Torque Parallel linkage
- Volvo attachment bracket
- Range of purpose-built attachments
- Custom-built attachment
- 3rd and 4th hydraulic functions



# Volvo Services

- Load Assist, powered by Volvo Co-Pilot
- Operator training
- Fuel Report
- Volvo ACTIVE CARE
- Genuine Volvo Parts

# **KEEP IT MOVING**

- 1000hr engine oil change interval
- Quick hydraulic oil fill thanks to new mounted nipple
- Improved cooling capacity
- Strong frame and central hinge
- Optional delayed engine shutdown
- Optional external axle cooling



# Safety as standard

- Anti-slip steps and strategically placed handrails
- Orange three-point seatbelt
- Redesigned side mirrors
- Rear-view camera

# **UP TO 20% MORE EFFICIENT**

- Optional lock-up converter
- Increased top speed of 50km/h with lock-up feature
- Rimpull control
- Smart Control
- Smooth Control
- Eco pedal

# Keep your machine moving

The latest generation Volvo L60H, L70H and L90H wheel loaders extends their already legendary status by offering an upgraded portfolio of uptime-enhancing features. From simplified serviceability to proactive dealer support, you have access to everything you need to keep your machine up and moving.

## Keep it cool

Count on Volvo to keep up. The improved cooling capacity regulates the component temperature, for greater machine utilization when using attachments that are demanding on the hydraulics, and longer hydraulic component life. This, plus the external axle cooling option – ideal for tough applications – doubles the axle oil change intervals for higher uptime and lower maintenance costs.



### **Greater access**

To keep uptime high, the H-Series wheel loaders are equipped with an engine cover that opens electronically, allowing ground-level access to the service points, including the radiator. For swift and easy cleaning, the new cooler installation now slides out. Safely fill the transmission and engine oil thanks to newly repositioned fill spouts, and get back to work without delay.



# Delayed engine shutdown

Reduce the wear on your engine with the new delayed engine shutdown feature. The optional function shuts off the machine when the turbo has cooled down to the ideal temperature. Not only does the feature reduce component wear, it can also be scheduled by the operator to activate automatically for added convenience.




# **Uptime Services**

Keep your machine moving with Uptime Services, a package of solutions designed to reduce your downtime and repair costs. Volvo ACTIVE CARE for example remotely monitors your machine's health, helping to predict potential failures before they occur. Take your pick from various Volvo Services and package them into a Volvo Services Agreement.



# DURABLE BY DESIGN

Built by Volvo, for Volvo, you can count on the proven design of the latest wheel loaders to meet the demands of tough job sites. Renowned for their reliability, the next-generation H-Series wheel loaders are built with an industry-leading, strong frame, which, combined with the ideally-matched genuine Volvo drivetrain, achieves long-lasting performance.



# Volvo L60H, L70H, L90H in detail

# Engine

6-cylinder, 6 liters inline turbocharged diesel engine with an advanced fuel injection system with the common rail. Fuel is distributed under high pressure from a high-pressure accumulator, the rail. One belt driven high pressure pump deliver the fuel to the rail and then further on via high-pressure pipes to the electronically operated fuel injectors. Engine meets Stage V emission legislation.

### L60H


Engine	Volvo	D6J
Max. power at	r/min	1500 - 1800
ISO 14396 gross	kW	122
	hp	166
ISO 9249, SAE J1349 net	kW	122
	hp	166
Max. torque at	r/min	1 500
SAE J1995 gross	Nm	820
ISO 9249, SAE J1349 net	Nm	820
Economic working range	r/min	800 - 1600
Displacement	1	5.7
17011		


#### L70H


L/011		
Engine	Volvo	D6J
Max. power at	r/min	1500 - 1800
ISO 14396 gross	kW	127
	hp	173
ISO 9249, SAE J1349 net	kW	127
	hp	173
Max. torque at	r/min	1400
SAE J1995 gross	Nm	853
ISO 9249, SAE J1349 net	Nm	853
Economic working range	r/min	800 - 1600
Displacement	1	5.7

# L90H

Engine	Volvo	D6J
Max. power at	r/min	1 400 - 1 900
ISO 14396 gross	kW	137
	hp	186
ISO 9249, SAE J1349 net	kW	137
	hp	186
Max. torque at	r/min	1 400
SAE J1995 gross	Nm	934
ISO 9249, SAE J1349 net	Nm	934
Economic working range	r/min	800 - 1600
Displacement	1	5.7







#### Drivetrain

Torque converter: Single-stage Transmission: Volvo countershaft transmission with single lever control. Fast and smooth shifting of gears with Pulse Width Modulation (PWM)

valve.
Transmission: Volvo Automatic Power Shift (APS) gear shifting system with fully automatic shifting 1-4 and mode selector with 4 different gear shifting programs, including AUTO mode. Also equipped with Rimpull control to avoid wheel spin and optimize bucket filling.

Axles: Volvo fully floating axle shafts with planetary hub reductions and cast steel axle housing. Fixed front axle and oscillating rear axle. 100%

differential lock on the front axle.		_
L60H		
Transmission	Volvo	HTE 125C Non Lock-up/ HTE 125 Lock-up
Torque multiplication, stall ratio		2.5:1 Non Lock-up / 2.59:1 Lock-up
Maximum speed		
1st gear	km/h	Converter 7.5 / Lock-up 7.5
2nd gear	km/h	Converter 15 / Lock-up 15
3rd gear	km/h	Converter 28 / Lock-up 29
4th gear	km/h	Converter 46 / Lock-up 50
4th gear: Shown in speedometer and li	mited l	by ECU
Measured with tires		20.5R25
Front axle/rear axle		AWB 15/AWB 15
Rear axle oscillation	±°	13
Ground clearance	mm	470
at oscillation	۰	13

L70H		
Transmission	Volvo	HTE 125C Non Lock-up / HTE 125 Lock-up
Torque multiplication, stall ratio		2.5:1 Non Lock-up / 2.59:1

Maximum speed	
1st gear	km/h Converter 7.5 / Lock-up 7.5
2nd gear	km/h Converter 15 / Lock-up 15
3rd gear	km/h Converter 29 / Lock-up 30
4th gear	km/h Converter 46 / Lock-up 50
Ath goars Chawn in speedamater and	limited by ECII

4th gear. Shown in speedometer and limited	by ECO
Measured with tires	
Front axle/rear axle	AWB

at oscillation	0	13
Ground clearance	mm	470
Rear axle oscillation	<u>+</u> °	13
Front axle/rear axle		AWB 25/AWB 20

# L90H

Transmission	Volvo	HTE 125C Non Lock-up/
Torque multiplication, stall ratio		2.5:1 Non Lock-up / 2.59:1 Lock-up
Maximum speed		
1st gear	km/h	Converter 6.5 / Lock-up 6.5
2nd gear	km/h	Converter 14 / Lock-up 14
3rd gear	km/h	Converter 26 / Lock-up 27
4th gear	km/h	Converter 46 / Lock-up 50

4th gear: Shown in speedometer and limited by ECU

Measured with tires		20.5R25
Front axle/rear axle		AWB 25/AWB 20
Rear axle oscillation	±°	13
Ground clearance	mm	470
at oscillation	۰	13

### **Electrical system**

Contronic electrical system with central warning light and buzzer for following functions: - Serious engine fault, Low steering system pressure, Over speed warning engine, Interruption in communication (computer fault), Central warning light and buzzer with the gear engaged for the following functions: Low engine oil pressure, High engine oil temperature, High charge air temperature, Low coolant level, High coolant temperature, High crank case pressure, Low transmission oil pressure, High transmission oil temperature, Low brake pressure, Engaged parking brake, Fault on brake charging, Low hydraulic oil level, High hydraulic oil temperature, Overspeeding in engaged gear, High brake cooling oil temperature front and rear axles, etc.

		L60H	L70H	L90H
Batteries	٧	2 x 12	2 x 12	2 x 12
Battery capacity	Ah	2 x 110	2 x 110	2 x 110
Cold cranking capacity, approx	А	680	680	680
Alternator rating	W/A	3 135/80	3 135/80	3 135/80
Starter motor output	kW	5.5	5.5	5.5

#### Brake system

20.5R25

Service brake: Volvo dual-circuit system with outboard mounted, hydraulically operated, fully sealed and circulating oil cooled wet disc brakes. Four operator selectable transmission disengagement settings while braking.

Parking brake: Dry disc brake mounted on the transmission output shaft. Applied by spring force, electro-hydraulically released with a switch on the instrument panel.

Secondary brake: Dual brake circuits with rechargeable accumulators. Standard: The brake system complies with the requirements of ISO 3450, 71/320/EEC

	L60H	L70H	L90H
Number of brake discs per wheel	1	1	1
Accumulators	I 3 x 0.5	2 x 0.5+1 x 1.0	2 x 0.5+1 x 1.0
Accumulators for parking brake	I 1 x 0.5	1 x 1.0	1 x 1.0

# Volvo L60H, L70H, L90H in detail

### Cab

Instrumentation: All important information is centrally located in the operator's field of vision. Display for Controlic monitoring system. Heater and defroster: Heater coil with filtered fresh air and fan with auto and 11 manual speed settings. Defroster vents for all window areas. Operator's seat: Operator's seat with adjustable air suspension and retractable seatbelt. The seat is mounted on a bracket on the rear cab wall and floor. The forces from the retractable seatbelt are absorbed by the seat

Standards: The cab is tested and approved according to ROPS (ISO 3471), FOPS (ISO 3449). The cab meets with requirements according to ISO 6055 (Operator overhead protection - Industrial trucks) and SAE J386 (Operator Restraint System)

		L60H	L70H	L90H				
Emergency exit: Use emergency hammer to break window								
Ventilation	m³/min	9	9	9				
Heating capacity	kW	16	16	16				
Air conditioning (optional)	kW	7.5	7.5	7.5				

#### Sound Level

	L60H	L70H	L90H
Sound pressure level in cab according to I	SO 6396		
$L_pA$ dB	68	68	68
External sound level according to ISO 639 2000/14/EC	95 and EU	Noise Dire	ctive
L <sub>WA</sub> dB	104	105	105

### Lift Arm System

Torque parallel linkage (TP-linkage) with high breakout torque and parallel

		L60H	L70H	L90H
Lift cylinders		2	2	2
Cylinder bore	mm	110	110	120
Piston rod diameter	mm	70	70	70
Stroke	mm	665	756	744
Tilt cylinder		1	1	1
Cylinder bore	mm	150	160	180
Piston rod diameter	mm	80	90	90
Stroke	mm	444	432	430

### Hydraulic system

Closed center load sensing hydraulic system with non pressurised hydraulic tank and pilot operated control valves. System supply: Variable displacement axial piston pump supply the

Valves: The central valve distributes pressure and flow out to the cooling fan, steering, brake, pilot and hydraulic system. Steering system gets priority over others

Lift function: The valve has four positions; raise, hold, lower and float

position. Automatic boom kickout positions; raise, noid, lower and libat position. Automatic boom kickout position can be set to any position between maximum reach and full lifting height.

Tilt function: The valve has three functions; rollback, hold and dump. Automatic tilt out/tilt in can be adjusted to the desired bucket angle. Cylinders: Double-acting cylinders for all functions.
Filter: Full flow filtration through 10 micron (absolute) filter cartridge.

		L60H	L70H	L90H
Working pressure maximum, pump 2 for steering-, brake-, pilot- and working hydraulic system	MPa	26	26	31
Flow	l/min	145	154	171
at	MPa	10	10	10
engine speed	r/min	1900	1900	1900
Working pressure maximum, pump 3 for brake- and cooling fan system	MPa	21	21	21
Flow	l/min	33	33	33
at	MPa	10	10	10
engine speed	r/min	1900	1900	1900
Pilot system, working pressure	MPa	3.5	3.5	3.5
Cycle times				
Lift	s	5.4	5.5	5.7
Tilt	s	1.9	2.1	2.3
Lower, empty	S	2.7	2.9	4
Total cycle time	s	10	10.5	12

# Steering System

System supply: The steering system has priority feed from a load-sensing axial piston pump with variable displacement. Steering cylinders: Two double-acting cylinders

		L60H	L70H	L90H
Steering cylinders		2	2	2
Cylinder bore	mm	70	70	80
Rod diameter	mm	45	45	50
Stroke	mm	386	386	345
Working pressure	MPa	21	21	21
Maximum flow	l/min	60	60	60
Maximum articulation	±°	40	40	40

Service accessibility: Large, electrically operated easy-to-open hood covering whole engine compartment. Fluid filters and component breather air filters are located from ground level access and promote long service intervals. Machine contronics have possibility to monitor, log and analyze data to facilitate troubleshooting. A quick-fit adapter on the hydraulic tank provides faster hydraulic oil fill.


promote in the second of the s				
		L60H	L70H	L90H
Fuel tank	- 1	222	222	222
DEF/AdBlue® tank	I	20	20	20
Engine coolant	- 1	30	30	30
Hydraulic oil tank	- 1	90	90	90
Transmission oil (non lock-up)	- 1	21	21	21
Transmission oil (lock-up)	I	22	22	22
Engine oil	- 1	20	20	20
Axle oil front	- 1	25	35	35
Axle oil rear	- 1	25	27	27


# **Specifications**

Tires 20.5 R25 L3								
		L60H	L70H	L90H	L60H	L70H	L90H	
		Sta	andard bo	om	L	ong boor	n	
В	mm	6 010	6 080	6 170	6 520	6 560	6 600	
С	mm	3 000	3 000	3 050	3 000	3 000	3 050	
D	mm	440	450	450	430	450	440	
F	mm	3 270	3 280	3 280	3 270	3 280	3 280	
G	mm	2 133	2 134	2 132	2 134	2 134	2 132	
J	mm	3 550	3 580	3 730	4 080	4 050	4 140	
K	mm	3 870	3 870	4 040	4 380	4 350	4 460	
0	0	56	56	57	56	52	58	
Pmax	0	45	46	45	42	45	44	
R	0	43	43	44	45	44	47	
R1*	0	46	48	49	50	49	53	
S	0	79	68	67	79	73	65	
Т	mm	123	106	112	150	112	123	
U	mm	410	450	480	590	500	570	
Χ	mm	1900	1930	1960	1900	1930	1960	
Υ	mm	2 430	2 460	2 490	2 430	2 460	2 490	
Z	mm	3 210	3 160	3 460	3 590	3 500	3 910	
a2	mm	5 340	5 350	5 430	5 340	5 350	5 430	
a3	mm	2 900	2 890	2 940	2 900	2 890	2 940	
a4	±°	40	40	40	40	40	40	

<sup>\*</sup> Carry position SAE


Where applicable, specifications and dimensions are according to ISO 7131, SAE J732, ISO 7546, SAE J742, ISO 14397, SAE J818





Tires: 20.5R25 L3				
		L60H	L70H	L90H
SAE-Load	kg	3 450	3 990	4 600
Operating weight without load*	kg	12 883	14 585	16 645
Grapple sales code		82 194	80 153	80 832
A	$m^2$	1.3	1.5	2.4
В	mm	3 412	3 380	3 487
С	mm	1483	1594	1703
D	mm	2 929	2 870	2 865
E	mm	1 175	1 265	1 319
F	mm	1532	1502	1 441
G	mm	2 350	2 442	2 740
Н	mm	4 333	4 378	4 613
1	mm	5 878	6 027	6 664
J	mm	1997	2 141	2 786
K	mm	2 080	2 365	2 990
L	mm	1709	1800	2 131
M	mm	7 861	7 996	8 469


<sup>\*</sup> Calculated with additional protective guarding



<sup>\*\*</sup>Calculated with additional protective guarding

# **Specifications**


Tires: 20.5R25 L3				
		L60H	L70H	L90H
Material handling arm sales c	ode	92007	92007	92008
A*	kg	1800	2 150	2 760
B*	kg	1400	1 710	2 130
C*	kg	1 150	1400	1740
Static tipping load, straight	kg	3 238	3 583	4 289
35deg. Turn	kg	2 910	3 222	3 834
at full turn	kg	2 814	3 116	3 700
D	mm	2 592	2 716	2 486
E	mm	2 002	2 106	1894
F	mm	1465	1 549	1 301
G	mm	3 270	3 323	3 253
Н	mm	4 305	4 358	4 387
I	mm	5 439	5 492	5 520
J	mm	905	1 269	1339
K	mm	1 2 2 7	1 744	1889
L	mm	1580	2 266	2 439
М	mm	2 258	2 176	2 051
N	mm	3 241	3 095	3 043
0	mm	4 319	4 102	4 034
Р	mm	1 512	1 523	1520
Q	mm	5 286	5 302	5 403
R	mm	6 171	6 174	6 370
S	mm	7 139	7 129	7 336
Operating weight without loa	d kg	11 885	13 451	14 833



<sup>\*\*</sup>Calculated with additional protective guarding

Tires: 20.5R25 L3								
		L60H	L70H	L90H				
Fork frame sales code		83768	83768	83770				
Fork tines sales code (R/L)		80042/80043	80042/80044	80106/80107				
Static tipping load, straight	kg	6 930	7 576	8 904				
35deg. Turn	kg	6 230	6 809	7 947				
at full turn	kg	6 024	6 584	7 664				
at load center distance*	mm	600	600	600				
Α	mm	798	841	932				
В	mm	1 567	1 616	1 679				
С	mm	-38	-52	-4				
D	mm	1 831	1859	1800				
E	mm	3 713	3 736	3 841				
F	mm	700	767	641				
Operating weight without load	kg	11 965	13 531	14 928				
Operating weight without load	kg	11 965	13 531	14 928				

<sup>\*</sup> Firm and level ground



<sup>\*</sup> Op. load at full turn + tipping position Tipping loads calculated for max. arm length

<sup>\*\*</sup>Calculated with additional protective guarding

# **Volvo L60H specifications**


L60H*											
BR 20,5R25 VJT L3			GENERAL PURPOSE					GRADING	LIGHT MATERIAL		LONG BOOM
		1.8 m <sup>3</sup> STE H T	1.9 m³ STE H BOE	2.1 m <sup>3</sup> STE P BOE	2.1 m <sup>3</sup> STE H BOE	2.3 m <sup>3</sup> STE P BOE	2.3 m <sup>3</sup> STE H BOE	1.7 m <sup>3</sup> GRB H BOE	3.1 m <sup>3</sup> LM H	5 m³ LM H	
Volume, heaped ISO/SAE	m³	1.8	1.9	2.1	2.1	2.3	2.3	1.7	3.1	5.0	0
Volume at 110% fill factor	m³	2.0	2.1	2.3	2.3	2.5	2.5	1.9	3.4	5.5	0
Static tipping load, straight	kg	9 020	8 860	9 270	8 760	9 190	8 650	7 750	8 460	8 470	-1820
at 35° turn	kg	8 080	7 930	8 320	7 830	8 240	7 730	6 930	7 550	7 520	-1 680
at full turn	kg	7 800	7 650	8 040	7 560	7 960	7 460	6 690	7 280	7 250	-1 640
Breakout force	kN	84.9	80.2	82.9	76.1	79.0	72.8	60.2	61.7	53.8	8.0
Α	mm	7 410	7 340	7 300	7 400	7 370	7 470	7 650	7 680	7 910	520
E	mm	1190	1140	1 110	1200	1 160	1 2 6 0	1400	1480	1700	50
Н	mm	2 750	2 800	2 820	2 760	2 780	2 720	2 510	2 580	2 430	550
L	mm	5 110	5 110	5 120	5 170	5 190	5 240	4 530	5 280	5 480	510
M	mm	1 070	1 050	1 020	1090	1 0 6 0	1 140	1 130	1320	1500	20
N	mm	1580	1590	1 570	1 610	1 590	1 630	1 490	1 630	1 670	450
V	mm	2 500	2 500	2 500	2 500	2 500	2 500	2 500	2 550	2 650	0
a1 clearance circle	mm	11 800	11 760	11 760	11 800	11 800	11 840	12 140	12 010	12 240	480
Operating weight	kg	12 260	12 320	12 120	12 360	12 160	12 400	12 260	12 450	12 740	230

<sup>\*</sup>Calculated with additional protective guarding.

### **Bucket Selection Chart**

The chosen bucket is determined by the density of the material and the expected bucket fill factor. The actual bucket volume is often larger than the rated capacity, due to the features of the TP linkage, including an open bucket design, good rollback angles in all positions and good bucket filling performance. The example represents a standard boom configuration. Example: Sand and gravel. Fill factor  $\sim 105\%$ . Density 1.65 t/m3. Result: The 1.9 m3 bucket carries 2.0 m3. For optimal stability always consult the bucket selection chart.

Material	Bucket fill, %	Material density, t/m³	ISO/SAE bucket volume, m3	Actual volume, m³
Earth/Clay	~ 110	~ 1.55 ~ 1.40 ~ 1.30	1.9 2.1 2.3	2.1 2.3 2.5
Sand/Gravel	~ 105	~ 1.65 ~ 1.50 ~ 1.35	1.9 2.1 2.3	2.0 2.2 2.1
Aggregate	~ 100	~ 1.75 ~ 1.55 ~ 1.55	1.9 2.1 2.3	1.9 2.1 2.3
Rock	≤100	~ 1.70	1.7	1.7



How to read bucket fill factor

<b>Supplemental Operating</b>	g Data				
			Standard boom		Long boom
Tires 20.5 R25 L3		17.5 R25 L2	20.5 R25 L2	600/65 R25 L3	600/65 R25 L3
Width over tires	mm	-130	+8	+96	+96
Ground clearance	mm	-68	-10	-30	-22
Tipping load, full turn	kg	-337	-166	-72	0
Operating weight	ka	-544	-112	+8	+3

Calculated with 2.3 m³ STE P BOE, additional protective guarding

# **Volvo L70H specifications**


L70H*											
BR 20,5R25 VJT L3			GENERAL PURPOSE				GRADING	LIGHT MATERIAL		LONG BOOM	
		2.1 m <sup>3</sup> STE H BOE	2.3 m <sup>3</sup> STE H T	2.3 m³ STE P BOE	2.3 m <sup>3</sup> STE H BOE	2.4 m <sup>3</sup> STE P BOE	2.4 m³ STE H BOE	2.2 m <sup>3</sup> GRB H BOE	3.4 m <sup>3</sup> LM H	6.4 m <sup>3</sup> LM H	
Volume, heaped ISO/SAE	m³	2.1	2.3	2.3	2.3	2.4	2.4	2.2	3.4	6.4	0
Volume at 110% fill factor	$m^3$	2.3	2.5	2.5	2.5	2.6	2.6	2.4	3.7	7.0	0
Static tipping load, straight	kg	9 750	9 640	10 280	9 680	10 240	9 640	7 930	9 270	8 840	-1 870
at 35° turn	kg	8 720	8 620	9 220	8 650	9 180	8 610	7 050	8 260	7 810	-1 720
at full turn	kg	8 420	8 310	8 910	8 340	8 870	8 310	6 790	7 960	7 500	-1 670
Breakout force	kN	90.3	87.0	97.2	88.2	93.5	85.1	62.8	71.8	53.9	-1.7
A	mm	7 480	7 610	7 400	7 510	7 450	7 570	7 960	7 780	8 330	470
Е	mm	1 180	1 290	1 100	1 210	1 150	1 260	1 670	1 470	1 970	30
Н	mm	2 760	2 670	2 810	2 730	2 780	2 700	2 350	2 530	2 150	480
L	mm	5 220	5 280	5 190	5 250	5 250	5 320	4 720	5 450	5 780	470
М	mm	1 140	1200	1 070	1 160	1 110	1190	1350	1340	1730	-40
N	mm	1 650	1 660	1 610	1 660	1 630	1 670	1 570	1 680	1 730	400
V	mm	2 550	2 550	2 650	2 650	2 550	2 550	2 650	2 650	2 750	0
a1 clearance circle	mm	11 850	11 930	11 910	11 960	11 850	11 900	12 480	12 140	12 600	430
Operating weight	kg	13 960	14 020	13 750	14 010	13 770	14 020	14 260	14 210	14 750	260

<sup>\*</sup>Calculated with additional protective guarding.

### **Bucket Selection Chart**

The chosen bucket is determined by the density of the material and the expected bucket fill factor. The actual bucket volume is often larger than the rated capacity, due to the features of the TP linkage, including an open bucket design, good rollback angles in all positions and good bucket filling performance. The example represents a standard boom configuration. Example: Sand and gravel. Fill factor  $\sim 105\%$ . Density 1.65 t/m3. Result: The 1.9 m3 bucket carries 2.0 m3. For optimal stability always consult the bucket selection chart.

Material	Bucket fill, %	Material density, t/m³	ISO/SAE bucket volume, m³	Actual volume, m³
Earth/Clay	~ 110	~ 1.55 ~ 1.45 ~ 1.40	2.1 2.3 2.4	2.3 2.6 2.6
Sand/Gravel	~ 105	~ 1.60 ~ 1.50 ~ 1.45	2.1 2.3 2.4	2.2 2.4 2.5
Aggregate	~ 100	~ 1.80 ~ 1.70 ~ 1.60	2.1 2.3 2.4	2.1 2.3 2.4
Rock	≤100	~ 1.70	1.6	1.6



<b>Supplemental Operating</b>	Data			
		Standard boom		Long boom
Tires 20.5 R25 L3		20.5 R25 L2	600/65 R25 L3	600/65 R25 L3
Width over tires	mm	+8	+96	+96
Ground clearance	mm	-8	-32	-24
Tipping load, full turn	kg	-62	-39	+9
Operating weight	kg	-113	+7	+4

Calculated with 2,3 m³ STE H BOE, additional protective guarding

# **Volvo L90H specifications**


L90H*											
BR 20,5R25 VJT L3		GENERAL PURPOSE				GRADING	LIGHT MATERIAL		LONG BOOM		
		6									
		2.3 m <sup>3</sup> STE H BOE	2.5 m <sup>3</sup> STE H T	2.5 m <sup>3</sup> STE P BOE	2.5 m <sup>3</sup> STE H BOE	2.6 m <sup>3</sup> STE P BOE	2.8 m <sup>3</sup> STE P BOE	2.8 m³ GRB H BOE	4.1 m <sup>3</sup> LM H	7 m³ LM H	
Volume, heaped ISO/SAE	m³	2.3	2.5	2.5	2.5	2.6	2.8	2.8	4.1	7.0	0
Volume at 110% fill factor	m³	2.5	2.8	2.8	2.8	2.9	3.1	3.1	4.5	7.7	0
Static tipping load, straight	kg	11 410	11 330	11 940	11 320	11 820	11 910	9 260	10 820	10 530	-1800
at 35° turn	kg	10 120	10 030	10 620	10 030	10 500	10 580	8 190	9 550	9 250	-1 650
at full turn	kg	9 730	9 650	10 220	9 650	10 110	10 190	7 870	9 180	8 870	-1 600
Breakout force	kN	134.9	129.9	141.3	127.1	133.8	135.6	92.2	100.7	87.0	1.7
A	mm	7 600	7 850	7 550	7 690	7 630	7 610	8 170	8 050	8 350	410
E	mm	1200	1 410	1 150	1280	1220	1 200	1 760	1 600	1860	-10
Н	mm	2 890	2 730	2 920	2 830	2 870	2 880	2 400	2 610	2 410	430
L	mm	5 450	5 510	5 440	5 530	5 520	5 500	4 900	5 630	5 840	420
M	mm	1 010	1 170	960	1 070	1 020	1000	1 210	1350	1560	-50
N	mm	1 670	1720	1 650	1 700	1 670	1 660	1 520	1 710	1 710	360
V	mm	2 650	2 650	2 650	2 500	2 500	2 750	2 880	2 750	3 000	0
a1 clearance circle	mm	12 140	12 290	12 130	12 060	12 040	12 250	12 980	12 500	12 920	340
Operating weight	kg	15 560	15 630	15 380	15 600	15 390	15 360	15 700	15 850	16 280	290

<sup>\*</sup>Calculated with additional protective guarding.

### **Bucket Selection Chart**

The chosen bucket is determined by the density of the material and the expected bucket fill factor. The actual bucket volume is often larger than the rated capacity, due to the features of the TP linkage, including an open bucket design, good rollback angles in all positions and good bucket filling performance. The example represents a standard boom configuration. Example: Sand and gravel. Fill factor  $\sim 105\%$ . Density 1.65 t/m3. Result: The 1.9 m3 bucket carries 2.0 m3. For optimal stability always consult the bucket selection chart.

Material	Bucket fill, %	Material density, t/m³	ISO/SAE bucket volume, m³	Actual volume, m³
Earth/Clay	~ 110	~ 1.55 ~ 1.45 ~ 1.40	2.1 2.3 2.4	2.3 2.5 2.6
Sand/Gravel	~ 105	~ 1.60 ~ 1.50 ~ 1.45	2.1 2.3 2.4	2.2 2.4 2.5
Aggregate	~ 100	~ 1.80 ~ 1.70 ~ 1.60	2.1 2.3 2.4	2.1 2.3 2.4
Rock	≤100	~ 1.70	1.6	1.6



<b>Supplemental Operating</b>	Data			
		Standa	rd boom	Long boom
Tires 20.5 R25 L3		20.5 R25 L2	650/65 R25 L3	650/65 R25 L3
Width over tires	mm	+4	+164	+164
Ground clearance	mm	-8	-4	+12
Tipping load, full turn	kg	-70	+315	+287
Operating weight	kg	-111	+545	+543

Calculated with 2.6 m³ STE P BOE, additional protective guarding

# **Equipment**

STANDARD EQUIPMENT			
	L60H	L70H	L90H
Engine			
Exhaust after-treatment system	•	•	•
3-stage air cleaner, pre-cleaner, primary and			
secondary filter			
Indicator glass for coolant level	•	•	•
Preheating of induction air	•	•	•
Fuel pre-filter with water trap	•	•	•
Fuel filter	•	•	•
Crank case breather oil trap	•	•	•
Exhaust heat ventilation	•	•	•
Tires			
17.5R25	•	-	-
20.5R25	•	•	•
Drivetrain			
Automatic Power Shift	•	•	•
Fully automatic gear shifting, 1-4	•	•	•
PWM-controlled gear shifting	•	•	•
Forward and reverse switch by hydraulic lever console	•	•	•
Rimpull control	•	•	•
Indicator glass for transmission oil level	•	•	•
Differentials: Front, 100% hydraulic diff lock. Rear, conventional	•	•	•
Electrical system			
24 V, pre-wired for optional accessories	•	•	•
Alternator 80A/3135W	•	•	•
Battery disconnect switch	•	•	•
Maintenance-free batteries	•	•	•
Battery box, steel	•	•	•
Fuel gauge	•	•	•
Electric horn	•	•	•
Instrument cluster:			
Fuel level	•	•	•
Diesel Exhaust Fluid/AdBlue level	•	•	•
Transmission temperature	•	•	•
Coolant temperature	•	•	
Instrument lighting	•	•	•
Lighting:			
Twin halogen front headlights with high and low beams	•	•	•
Parking lights	•		
Double brake and tail lights	•	•	•
Turn signals with flashing hazard light function	•		
Halogen work lights (2 front and 2 rear)	•	•	•
J			

Contronic display Fuel consumption Diesel Exhaust Fluid/AdBlue consumption Ambient temperature Clock Test function for warning and indicator lights Brake test Warning and indicator lights: Battery charging Parking brake Warning and display message: Regeneration Engine coolant temperature Charge air temperature Engine oil pressure Transmission oil temperature Brake pressure Parking brake applied Brake charging Overspeed at direction change Axle oil temperature Steering pressure Attachment lock open Level warnings: Fuel level Washer fluid level Engine coolant temperature Ingine coolant temperature Transmission oil temperature  Fransmisor oil pressure  Hydraulic oil temperature  Fransmission oil pressure  Axle oil temperature Steering pressure  Attachment lock open Level warnings: Fuel level Washer fluid level Hydraulic oil level Washer fluid level Hydraulic oil temperature High engine coolant temperature High engine colant temperature High crank case pressure High crank case of malfunction indication:	STANDARD EQUIPMENT			
Contronic display Fuel consumption Diesel Exhaust Fluid/AdBlue consumption Ambient temperature Clock Test function for warning and indicator lights Brake test Warning and indicator lights: Battery charging Parking brake Warning and display message: Regeneration Engine coolant temperature Charge air temperature Engine oil pressure Transmission oil temperature Brake pressure Brake pressure Brake pressure Brake darging Overspeed at direction change Axle oil temperature Steering pressure Attachment lock open Level warnings: Fuel level Washer fluid level Engine coolant temperature High engine collant temperature High engine collant temperature Finansmission oil temperature  Transmission oil pressure  Attachment lock open Level warnings: Fuel level Washer fluid level Hydraulic oil temperature High engine colant temperature High engine colant temperature High crank case pressure High crank case of malfunction indication:		L60H	L70H	L90H
Fuel consumption Diesel Exhaust Fluid/AdBlue consumption Ambient temperature Clock Test function for warning and indicator lights Brake test Warning and indicator lights: Battery charging Parking brake Warning and display message: Regeneration Engine coolant temperature Charge air temperature Engine oil temperature Engine oil temperature Transmission oil pressure Hydraulic oil temperature Brake charging Overspeed at direction change Axle oil temperature Steering pressure Crank case pressure Crank case pressure Crank colont level Engine coolant level Engine coolant tewel Engine oil temperature Brake charging Overspeed at direction change Axle oil temperature Steering pressure Crank case pressure Cr	Contronic monitoring system			
Fuel consumption Diesel Exhaust Fluid/AdBlue consumption Ambient temperature Clock Test function for warning and indicator lights Brake test Warning and indicator lights: Battery charging Parking brake Warning and display message: Regeneration Engine coolant temperature Charge air temperature Engine oil temperature Engine oil temperature Transmission oil pressure Hydraulic oil temperature Brake charging Overspeed at direction change Axle oil temperature Steering pressure Crank case pressure Crank case pressure Crank colant level Engine coolant level Engine coolant level Engine oil temperature  Engine oil temperature  Brake charging Coverspeed at direction change Axle oil temperature Steering pressure Crank case press	Contronic display	•	•	•
Ambient temperature Clock Test function for warning and indicator lights Brake test Warning and indicator lights: Battery charging Parking brake Warning and display message: Regeneration Engine coolant temperature Charge air temperature Engine oil pressure Transmission oil temperature Transmission oil temperature Brake pressure Parking brake applied Brake charging Overspeed at direction change Axle oil temperature Steering pressure Crank case pressure Attachment lock open Level warnings: Fuel level Diesel Exhaust Fluid/AdBlue level Engine coolant temperature High engine collant temperature High engine collant temperature High engine collant temperature High engine oil pressure High charge air temperature		•	•	•
Clock Test function for warning and indicator lights Brake test Warning and indicator lights: Battery charging Parking brake Warning and display message: Regeneration Engine coolant temperature Charge air temperature Engine oil pressure Transmission oil temperature Brake pressure Parking brake  Warning and display message:  Regeneration Engine coolant temperature  Engine oil pressure Transmission oil temperature Transmission oil temperature Transmission oil pressure Parking brake applied Brake charging Overspeed at direction change Axle oil temperature Steering pressure Crank case pressure Attachment lock open Level warnings: Fuel level Diesel Exhaust Fluid/AdBlue level Engine coolant level Transmission oil level Hydraulic oil level Washer fluid level Engine torque reduction in case of malfunction indication: High engine collant temperature Low engine oil pressure Engine shutdown to idle in case of malfunction indication:	Diesel Exhaust Fluid/AdBlue consumption	•	•	•
Test function for warning and indicator lights Brake test  Warning and indicator lights: Battery charging Parking brake  Warning and display message: Regeneration Engine coolant temperature Charge air temperature Engine oil temperature Engine oil pressure Transmission oil temperature Brake pressure Parking brake applied Brake charging Overspeed at direction change Axle oil temperature Steering pressure Crank case pressure Attachment lock open Level warnings: Fuel level Diesel Exhaust Fluid/AdBlue level Engine coolant level Transmission oil level Wydraulic oil temperature  Engine coolant level Transmission oil level Hydraulic oil temperature  Engine coolant level Transmission oil level Hydraulic oil level Washer fluid level Engine coolant temperature High engine colant temperature Low engine oil pressure Indication: High engine colant temperature High charge air temperature Engine shutdown to idle in case of malfunction indication:	Ambient temperature	•	•	•
Brake test  Warning and indicator lights:  Battery charging Parking brake  Warning and display message: Regeneration Regeneration Regine coolant temperature Charge air temperature Engine oil temperature Engine oil pressure Transmission oil temperature Transmission oil temperature Brake pressure Parking brake applied Brake charging Overspeed at direction change Axle oil temperature Steering pressure Crank case pressure Attachment lock open Level warnings: Fuel level Diesel Exhaust Fluid/AdBlue level Engine coolant level Hydraulic oil level Washer fluid level Engine torque reduction in case of malfunction indication: High engine colle in case of malfunction indication: Engine shutdown to idle in case of malfunction indication:	Clock	•	•	•
Warning and indicator lights: Battery charging Parking brake Warning and display message: Regeneration Engine coolant temperature Charge air temperature Engine oil temperature Engine oil pressure Transmission oil temperature Transmission oil pressure Hydraulic oil temperature Brake pressure Parking brake applied Brake charging Overspeed at direction change Axle oil temperature Steering pressure Crank case pressure Attachment lock open Level warnings: Fuel level Diesel Exhaust Fluid/AdBlue level Engine coolant level Transmission oil level Washer fluid level Engine torque reduction in case of malfunction indication: High engine collant temperature Engine shutdown to idle in case of malfunction indication:	Test function for warning and indicator lights	•	•	•
Battery charging Parking brake Warning and display message: Regeneration Engine coolant temperature Charge air temperature Engine oil temperature Engine oil temperature Engine oil temperature Engine oil pressure Transmission oil temperature Transmission oil pressure Hydraulic oil temperature Brake pressure Parking brake applied Brake charging Overspeed at direction change Axle oil temperature Steering pressure Crank case pressure Crank case pressure  Attachment lock open Level warnings: Fuel level Diesel Exhaust Fluid/AdBlue level Engine coolant level Hydraulic oil level Washer fluid level Engine torque reduction in case of malfunction indication: High engine collant temperature High engine oil temperature High charge air temperature Engine shutdown to idle in case of malfunction indication:	Brake test	•	•	•
Parking brake  Warning and display message:  Regeneration  Engine coolant temperature  Charge air temperature  Engine oil pressure  Fransmission oil temperature  Brake pressure  Parking brake applied  Brake charging  Overspeed at direction change  Axle oil temperature  Crank case pressure  Crank case pressure  Attachment lock open  Level warnings:  Fuel level  Diesel Exhaust Fluid/AdBlue level  Engine coolant level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine oil pressure  Engine shutdown to idle in case of malfunction indication:  Engine shutdown to idle in case of malfunction indication:	Warning and indicator lights:			
Warning and display message:  Regeneration  Engine coolant temperature  Charge air temperature  Engine oil temperature  Engine oil pressure  Transmission oil temperature  Brake pressure  Parking brake applied  Brake charging  Overspeed at direction change  Axle oil temperature  Steering pressure  Crank case pressure  Attachment lock open  Level warnings:  Fuel level  Diesel Exhaust Fluid/AdBlue level  Engine coolant level  Transmission oil level  Hydraulic oil temperature  Diesel Exhaust Fluid/adBlue level  Engine coolant level  Transmission oil level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine collant temperature  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Battery charging	•	•	•
Regeneration Engine coolant temperature Charge air temperature Engine oil temperature Engine oil temperature Engine oil pressure Transmission oil temperature Transmission oil temperature Transmission oil pressure Hydraulic oil temperature Brake pressure Parking brake applied Brake charging Overspeed at direction change Axle oil temperature Steering pressure Crank case pressure Crank case pressure Crank case pressure Level warnings: Fuel level Diesel Exhaust Fluid/AdBlue level Engine coolant level Transmission oil level Hydraulic oil level Washer fluid level Engine torque reduction in case of malfunction indication: High engine collant temperature Low engine oil pressure High charge air temperature Engine shutdown to idle in case of malfunction indication:	Parking brake	•	•	•
Engine coolant temperature  Charge air temperature  Engine oil temperature  Engine oil pressure  Transmission oil temperature  Brake pressure  Parking brake applied  Brake charging  Overspeed at direction change  Axle oil temperature  Steering pressure  Crank case pressure  Crank case pressure  Attachment lock open  Level warnings:  Fuel level  Diesel Exhaust Fluid/AdBlue level  Engine coolant level  Transmission oil level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine collant temperature  High engine oil temperature  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Warning and display message:	•	•	•
Charge air temperature Engine oil temperature Engine oil pressure Transmission oil temperature Transmis prake applied Transmis direction change Transmis case pressure Transmis case pressure Transmis colant lock open Transmission oil level Transmis colant temperature Tran	Regeneration	•	•	•
Engine oil temperature  Engine oil pressure  Transmission oil temperature  Transmission oil temperature  Transmission oil pressure  Hydraulic oil temperature  Brake pressure  Parking brake applied  Brake charging  Overspeed at direction change  Axle oil temperature  Steering pressure  Crank case pressure  Crank case pressure  Attachment lock open  Level warnings:  Fuel level  Diesel Exhaust Fluid/AdBlue level  Engine coolant level  Transmission oil level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine oil temperature  High crank case pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Engine coolant temperature	•	•	•
Engine oil pressure  Transmission oil temperature  Transmission oil temperature  Transmission oil pressure  Hydraulic oil temperature  Brake pressure  Parking brake applied  Brake charging  Overspeed at direction change  Axle oil temperature  Steering pressure  Crank case pressure  Crank case pressure  Level warnings:  Fuel level  Diesel Exhaust Fluid/AdBlue level  Engine coolant level  Transmission oil level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine oil temperature  High crank case pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Charge air temperature	•	•	•
Transmission oil temperature  Transmission oil pressure Hydraulic oil temperature Brake pressure Parking brake applied Brake charging Overspeed at direction change Axle oil temperature Steering pressure Crank case pressure Crank case pressure Crank case pressure Level warnings: Fuel level Diesel Exhaust Fluid/AdBlue level Engine coolant level Hydraulic oil level Washer fluid level Engine torque reduction in case of malfunction indication: High engine oil pressure High charge air temperature Engine shutdown to idle in case of malfunction indication: Engine shutdown to idle in case of malfunction indication:	Engine oil temperature	•	•	•
Transmission oil pressure Hydraulic oil temperature Brake pressure Parking brake applied Brake charging Overspeed at direction change Axle oil temperature Steering pressure Crank case pressure Crank case pressure Attachment lock open Level warnings: Fuel level Diesel Exhaust Fluid/AdBlue level Engine coolant level Hydraulic oil level Washer fluid level Engine torque reduction in case of malfunction indication: High engine oil pressure High charge air temperature Engine shutdown to idle in case of malfunction indication: Engine shutdown to idle in case of malfunction indication:	Engine oil pressure	•	•	•
Hydraulic oil temperature  Brake pressure  Parking brake applied  Brake charging  Overspeed at direction change  Axle oil temperature  Steering pressure  Crank case pressure  Attachment lock open  Level warnings:  Fuel level  Diesel Exhaust Fluid/AdBlue level  Engine coolant level  Transmission oil level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine oil temperature  Low engine oil pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Transmission oil temperature	•	•	•
Brake pressure Parking brake applied Brake charging Overspeed at direction change Axle oil temperature Steering pressure Crank case pressure Attachment lock open Level warnings: Fuel level Diesel Exhaust Fluid/AdBlue level Engine coolant level Transmission oil level Hydraulic oil level Washer fluid level Engine torque reduction in case of malfunction indication: High engine oil temperature High charge air temperature Engine shutdown to idle in case of malfunction indication:	Transmission oil pressure	•	•	•
Parking brake applied  Brake charging  Overspeed at direction change  Axle oil temperature  Steering pressure  Crank case pressure  Attachment lock open  Level warnings: Fuel level  Diesel Exhaust Fluid/AdBlue level  Engine coolant level  Transmission oil level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine oil temperature  Low engine oil pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Hydraulic oil temperature	•	•	•
Brake charging Overspeed at direction change Axle oil temperature Steering pressure Crank case pressure Attachment lock open Level warnings: Fuel level Diesel Exhaust Fluid/AdBlue level Engine coolant level Transmission oil level Hydraulic oil level Washer fluid level Engine torque reduction in case of malfunction indication: High engine oil temperature Low engine oil pressure High charge air temperature Engine shutdown to idle in case of malfunction indication:	Brake pressure	•	•	•
Overspeed at direction change  Axle oil temperature  Steering pressure  Crank case pressure  Attachment lock open  Level warnings: Fuel level  Diesel Exhaust Fluid/AdBlue level  Engine coolant level  Transmission oil level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine oil temperature  Low engine oil pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Parking brake applied	•	•	•
Axle oil temperature  Steering pressure  Crank case pressure  Attachment lock open  Level warnings:  Fuel level  Diesel Exhaust Fluid/AdBlue level  Engine coolant level  Transmission oil level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine oil temperature  Low engine oil pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Brake charging	•	•	•
Steering pressure  Crank case pressure  Attachment lock open  Level warnings:  Fuel level  Diesel Exhaust Fluid/AdBlue level  Engine coolant level  Transmission oil level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine collant temperature  Low engine oil pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Overspeed at direction change	•	•	•
Crank case pressure Attachment lock open Level warnings: Fuel level Diesel Exhaust Fluid/AdBlue level Engine coolant level Transmission oil level Hydraulic oil level Washer fluid level Engine torque reduction in case of malfunction indication: High engine collant temperature Low engine oil pressure High charge air temperature Engine shutdown to idle in case of malfunction indication:	Axle oil temperature	•	•	•
Attachment lock open  Level warnings:  Fuel level  Diesel Exhaust Fluid/AdBlue level  Engine coolant level  Transmission oil level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine colant temperature  Low engine oil temperature  High crank case pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Steering pressure	•	•	•
Level warnings:  Fuel level  Diesel Exhaust Fluid/AdBlue level  Engine coolant level  Transmission oil level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine coolant temperature  Low engine oil temperature  High crank case pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Crank case pressure	•	•	•
Fuel level  Diesel Exhaust Fluid/AdBlue level  Engine coolant level  Transmission oil level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine coolant temperature  High engine oil temperature  Low engine oil pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Attachment lock open	•	•	•
Diesel Exhaust Fluid/AdBlue level  Engine coolant level  Transmission oil level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine coolant temperature  High engine oil temperature  Low engine oil pressure  High crank case pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Level warnings:			
Engine coolant level  Transmission oil level  Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine coolant temperature  High engine oil temperature  Low engine oil pressure  High crank case pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Fuel level	•	•	•
Transmission oil level Hydraulic oil level Washer fluid level Engine torque reduction in case of malfunction indication: High engine coolant temperature High engine oil temperature Low engine oil pressure High crank case pressure High charge air temperature Engine shutdown to idle in case of malfunction indication:	Diesel Exhaust Fluid/AdBlue level	•	•	•
Hydraulic oil level  Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine coolant temperature  High engine oil temperature  Low engine oil pressure  High crank case pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Engine coolant level	•	•	•
Washer fluid level  Engine torque reduction in case of malfunction indication:  High engine coolant temperature  High engine oil temperature  Low engine oil pressure  High crank case pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Transmission oil level	•	•	•
Engine torque reduction in case of malfunction indication:  High engine coolant temperature  High engine oil temperature  Low engine oil pressure  High crank case pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Hydraulic oil level	•	•	•
indication:  High engine coolant temperature  High engine oil temperature  Low engine oil pressure  High crank case pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Washer fluid level	•	•	•
High engine coolant temperature  High engine oil temperature  Low engine oil pressure  High crank case pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:	Engine torque reduction in case of malfunction			
High engine oil temperature  Low engine oil pressure  High crank case pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:				
Low engine oil pressure High crank case pressure High charge air temperature Engine shutdown to idle in case of malfunction indication:		•	•	•
High crank case pressure  High charge air temperature  Engine shutdown to idle in case of malfunction indication:		•	•	•
High charge air temperature  Engine shutdown to idle in case of malfunction indication:		•	•	•
Engine shutdown to idle in case of malfunction indication:		•	•	•
indication:		•	•	•
High transmission oil temperature • • •	· · ·			
5 r r r r r r r r r r r r r r r r r r r	High transmission oil temperature	•	•	•
Slip in transmission clutches • • •	Slip in transmission clutches	•	•	•
Key pad, background lit • • •	Key pad, background lit	•	•	•
Start interlock when gear is engaged • • •	Start interlock when gear is engaged	•	•	•

Hydraulic system  Main valve, double acting 2-spool with hydraulic pilots  Variable displacement axial piston pumps (2) for:  Working hydraulics, pilot hydraulics, steering system, brakes  Cooling fan, brakes  Hydraulic control levers  Mechanical hydraulic lever lock  Automatic boom kick-out  Automatic bucket positioner  Double acting hydraulic cylinders  Indicator glass for hydraulic oil level Hydraulic oil cooler  Brake system  Dual brake circuits  Dual brake circuits  Dual brake, electrical-hydraulic  Brake wear indicators  Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449)  Single key kit door/start  Acoustic inner lining  Cigarette lighter, 24 V power outlet  Lockable door  Cab heating with fresh air inlet and defroster	· · · · · · · · · · · · · · · · · · ·
Main valve, double acting 2-spool with hydraulic pilots  Variable displacement axial piston pumps (2) for:  Working hydraulics, pilot hydraulics, steering system, brakes  Cooling fan, brakes  Hydraulic control levers  Mechanical hydraulic lever lock  Automatic boom kick-out  Automatic bucket positioner  Double acting hydraulic cylinders Indicator glass for hydraulic oil level  Hydraulic oil cooler  Brake system  Dual brake circuits  Dual brake pedals  Secondary brake system  Parking brake, electrical-hydraulic  Brake wear indicators  Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449)  Single key kit door/start  Acoustic inner lining  Cigarette lighter, 24 V power outlet  Lockable door	•
Variable displacement axial piston pumps (2) for:  Working hydraulics, pilot hydraulics, steering system, brakes  Cooling fan, brakes  Hydraulic control levers  Mechanical hydraulic lever lock  Automatic boom kick-out  Automatic bucket positioner  Double acting hydraulic cylinders Indicator glass for hydraulic oil level  Hydraulic oil cooler  Brake system  Dual brake circuits  Dual brake pedals  Secondary brake system  Parking brake, electrical-hydraulic  Brake wear indicators  Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449)  Single key kit door/start  Acoustic inner lining  Cigarette lighter, 24 V power outlet  Lockable door	•
Working hydraulics, pilot hydraulics, steering system, brakes  Cooling fan, brakes  Hydraulic control levers  Mechanical hydraulic lever lock  Automatic boom kick-out  Automatic bucket positioner  Double acting hydraulic cylinders Indicator glass for hydraulic oil level  Hydraulic oil cooler  Brake system  Dual brake circuits  Dual brake pedals  Secondary brake system  Parking brake, electrical-hydraulic  Brake wear indicators  Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449)  Single key kit door/start  Acoustic inner lining  Cigarette lighter, 24 V power outlet  Lockable door	
Cooling fan, brakes Hydraulic control levers Mechanical hydraulic lever lock Automatic boom kick-out Automatic bucket positioner Double acting hydraulic cylinders Indicator glass for hydraulic oil level Hydraulic oil cooler  Brake system Dual brake circuits Dual brake pedals Secondary brake system Parking brake, electrical-hydraulic Brake wear indicators Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab ROPS (ISO 3471), FOPS (ISO 3449) Single key kit door/start Acoustic inner lining Cigarette lighter, 24 V power outlet Lockable door	
Hydraulic control levers  Mechanical hydraulic lever lock  Automatic boom kick-out  Automatic bucket positioner  Double acting hydraulic cylinders Indicator glass for hydraulic oil level  Hydraulic oil cooler  Brake system  Dual brake circuits  Dual brake pedals  Secondary brake system  Parking brake, electrical-hydraulic  Brake wear indicators  Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449)  Single key kit door/start  Acoustic inner lining  Cigarette lighter, 24 V power outlet  Lockable door	
Mechanical hydraulic lever lock Automatic boom kick-out Automatic bucket positioner  Double acting hydraulic cylinders Indicator glass for hydraulic oil level Hydraulic oil cooler  Brake system  Dual brake circuits Dual brake pedals Secondary brake system Parking brake, electrical-hydraulic Brake wear indicators Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449) Single key kit door/start Acoustic inner lining Cigarette lighter, 24 V power outlet Lockable door	•
Automatic bucket positioner  Double acting hydraulic cylinders Indicator glass for hydraulic oil level Hydraulic oil cooler  Brake system  Dual brake circuits Dual brake pedals Secondary brake system Parking brake, electrical-hydraulic Brake wear indicators Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449) Single key kit door/start Acoustic inner lining Cigarette lighter, 24 V power outlet Lockable door	•
Double acting hydraulic cylinders Indicator glass for hydraulic oil level Hydraulic oil cooler  Brake system  Dual brake circuits Dual brake pedals Secondary brake system Parking brake, electrical-hydraulic Brake wear indicators Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449) Single key kit door/start Acoustic inner lining Cigarette lighter, 24 V power outlet Lockable door	•
Indicator glass for hydraulic oil level Hydraulic oil cooler  Brake system  Dual brake circuits  Dual brake pedals Secondary brake system Parking brake, electrical-hydraulic Brake wear indicators Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449) Single key kit door/start Acoustic inner lining Cigarette lighter, 24 V power outlet Lockable door	•
Hydraulic oil cooler  Brake system  Dual brake circuits  Dual brake pedals  Secondary brake system  Parking brake, electrical-hydraulic  Brake wear indicators  Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449)  Single key kit door/start  Acoustic inner lining  Cigarette lighter, 24 V power outlet  Lockable door	•
Brake system  Dual brake circuits  Dual brake pedals  Secondary brake system  Parking brake, electrical-hydraulic  Brake wear indicators  Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449)  Single key kit door/start  Acoustic inner lining  Cigarette lighter, 24 V power outlet  Lockable door	•
Dual brake circuits  Dual brake pedals  Secondary brake system  Parking brake, electrical-hydraulic  Brake wear indicators  Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449)  Single key kit door/start  Acoustic inner lining  Cigarette lighter, 24 V power outlet  Lockable door	•
Secondary brake system Parking brake, electrical-hydraulic Brake wear indicators Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449) Single key kit door/start Acoustic inner lining Cigarette lighter, 24 V power outlet Lockable door	•
Parking brake, electrical-hydraulic Brake wear indicators Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449) Single key kit door/start Acoustic inner lining Cigarette lighter, 24 V power outlet Lockable door	•
Brake wear indicators Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449) Single key kit door/start Acoustic inner lining Cigarette lighter, 24 V power outlet Lockable door	•
Outboard mounted circulating oil cooled wet disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449)  Single key kit door/start  Acoustic inner lining  Cigarette lighter, 24 V power outlet  Lockable door	•
disc brakes on all four wheels  Cab  ROPS (ISO 3471), FOPS (ISO 3449)  Single key kit door/start  Acoustic inner lining  Cigarette lighter, 24 V power outlet  Lockable door	•
ROPS (ISO 3471), FOPS (ISO 3449)  Single key kit door/start  Acoustic inner lining  Cigarette lighter, 24 V power outlet  Lockable door	
Single key kit door/start  Acoustic inner lining  Cigarette lighter, 24 V power outlet  Lockable door  • • • • • • • • • • • • • • • • • •	•
Acoustic inner lining  Cigarette lighter, 24 V power outlet  Lockable door  • • •	•
Cigarette lighter, 24 V power outlet  Lockable door  • •	•
Cab heating with fresh air inlet and defroster	•
oub heading with hear all filler and demoster	•
Fresh air inlet with two filters • •	•
Automatic heat control • •	•
Floor mat  • • •  Dual interior lights	•
Dual interior lights  Interior rearview mirrors  • • •	
Dual exterior rearview mirrors • •	
Sliding window, right side • •	•
Tinted safety glass • •	•
Retractable seatbelt (SAE J386) • •	•
Adjustable steering wheel	•
Storage compartment • • • • • • • • • • • • • • • • • • •	•
Document pocket  Sun visor  • • •	•
Beverage holder • •	
Windshield washer front and rear • •	•
Windshield wipers front and rear • •	•
Interval function for front and rear wipers • •	•
Foot step, left side (toolbox lockable included)  • •	•
Service and maintenance Engine oil remote drain and fill  • •	•
Transmission oil remote drain and fill	
Sliding hydraulic oil cooler and AC-condenser • •	•
Lubrication manifolds, ground accessible • •	•
Pressure test ports: transmission and hydraulic, quick connects	•
Service platforms with anti-slip surfaces • •	•
Quick-fit hydraulic oil fill • •	•
CareTrack • •	•
Telematics, 6 -year subscription • •	•
Toolbox, lockable • • • • • External equipment	•
Basic fenders, front and rear • •	•
Viscous cab mounts • •	
Viscous cab mounts • • • Rubber engine and transmission mounts • • • • • • • • • • • • • • • • • • •	•
Rubber engine and transmission mounts  Engine hood, electronically openable  • •	•
Rubber engine and transmission mounts  Engine hood, electronically openable  Frame, joint lock  • • •	•
Rubber engine and transmission mounts  Engine hood, electronically openable  Frame, joint lock  Vandalism lock for engine compartment  •	•
Rubber engine and transmission mounts  Engine hood, electronically openable  Frame, joint lock  Vandalism lock for engine compartment  Lifting eyes	•
Rubber engine and transmission mounts  Engine hood, electronically openable  Frame, joint lock  Vandalism lock for engine compartment	•

OPTIONAL EQUIPMENT			
	L60H	L70H	L90H
Engine			
Air pre-cleaner, cyclone type	•	•	•
Air pre-cleaner, oil-bath type	•	•	•
Air pre-cleaner, turbo type	•	•	•
Engine auto shut down	•	•	•
Engine block heater, 120V / 230V	•	•	•
Fuel heater	•	•	•
Fuel fill strainer	•	•	•
Hand throttle control	•	•	•
Max. fan speed, hot climate	•	•	•
Reversible cooling fan	•	•	•
Drivetrain			
Lock-up torque converter	•	•	•
Rear axle with limited slip	•	•	•
Speed limiter, 20 km/h	•	•	•
Speed limiter, 30 km/h	•	•	•
Speed limiter, 40 km/h	•	•	•
Hydraulic system			
Arctic kit: Attachment locking, pilot hoses and			
hydraulic oil			
Attachment bracket, cast, visibility-optimized	•	•	•
Attachment bracket, side-tilting	•	•	•
Separate attachment locking, long boom	•	•	•
Separate attachment locking, standard boom	•	•	•
Single acting lifting function	•	•	•
Boom suspension system	•	•	•
HD load-sensing hydraulics, pump kit included	-	•	_
Hydraulic fluid, biodegradable, Volvo	•	•	•
Hydraulic fluid, fire resistant	•	•	•
Hydraulic fluid, for hot climate	•	•	•
Hydraulic, 3 functions, standard/long boom	•	•	•
Hydraulic, 4 functions, standard/long boom	•	•	•
Detent for 3rd hydraulic function	•	•	•
Adjustable flow for 3rd hydraulic function	•	•	•
Single lever control, 2 functions	•	•	•
Single lever control, 3 functions	•	•	•
Hydraulic, 2 functions Electro-servo, std/long boom	•	•	•
Hydraulic, 3 functions Electro-servo, std/long boom	•	•	•
Hydraulic, 4 functions Electro-servo, std/long boom	•	•	•
Single lever control, 2 funct Electro-servo, std/			
long boom			
Single lever control, 3 funct Electro-servo, std/ long boom	•	•	•
Single lever control, 4 funct Electro-servo, std/			
long boom	•	•	•
Brake system			
Stainless steel, brake lines	-	•	•
Axle oil cooler	_	•	•
Parking brake alarm, audible	•	•	•

# **Equipment**

OPTIONAL EQUIPMENT			
	L60H	L70H	L90H
Cab			
ACC control panel, with Fahrenheit scale	•	•	•
Anchorage for Operator's manual	•	•	•
Asbestos dust protection filter	•	•	•
Automatic Climate Control, ACC	•	•	•
Automatic Climate Control, ACC, corrosion			
protection condenser			
Cab air pre-cleaner, cyclone type	•	•	•
Carbon filter - cab	•	•	•
Remote door opener	•	•	•
Lunch box holder	•	•	•
Operator's seat, Volvo air-suspended, heavy-	•	•	•
duty, high back, heated			
Operator's seat, Volvo air-susp, 3-point seatbelt	•	•	•
Operator's seat, ISRI, heated, high back	•	•	•
Operator's seat, ISRI, low back	•	•	•
Operator's seat, Premium Comfort ISRI	•	•	•
Operator's seat, Premium Comfort ISRI 3-point seat belt	•	•	•
Armrest, operator's seat, ISRI, left only	•	•	•
Armrest, operator's seat, Volvo, left	•	•	•
Safety belt, 3" (75mm) width	•	•	•
Safety belt warning	•	•	•
Radio installation kit including 12 volt outlet, left-side	•	•	•
Radio installation kit including 12 volt outlet, right-side	•	•	•
Radio installation kit, 12V, for USA			•
Radio with AUX, Bluetooth and USB connection	•	•	•
DAB Radio	•		
Subwoofer	•	•	•
Forward view mirror	•	•	•
Rear view mirrors, el.adjusted and heated	•	•	•
Rear view mirrors, long arm right	•	•	•
Rear view mirrors, el.adjusted and heated, long			
arm right	•	•	•
Steering wheel knob	•	•	•
Sun blinds, rear windows	•	•	•
Sun blinds, side windows	•	•	•
Timer cab heating	•	•	•
Universal door/ignition key	•	•	•
Window, sliding, door	•	•	•
Cab, Hot applications. Roof, steel	•	•	•
Fire extinguisher cab	•	•	•
Outside steel protection cab	•	•	•
Rear view mirrors long arm, cab	•	•	•
Reinforced windshield, flat	•	•	•
Service and maintenance			
Automatic lubrication system	•	•	•
Automatic lubrication system for long boom	•	٠	•
Oil sampling valve	•	•	•
Refill pump for automatic lubrication system	•	٠	•
Tool kit	•	•	•
Wheel nut wrench kit	•	•	•

OPTIONAL EQUIPMENT			
	L60H	L70H	L90H
Electrical			
Battery disconnect switch, additional in cab	•	•	•
Anti-theft device	•	•	•
Headlights, assym. left	•	•	•
Headlights, assym. right LED	•	•	•
Headlights, assym. left LED	•	•	•
Emergency stop	•	•	•
License plate holder, lighting Reduced function working lights when reverse		•	•
gear activated	•	•	•
Side marker lamps	•	•	•
Forward camera, colour		•	
Rear view camera including monitor, colour	•	•	•
Rear view mirrors, long arm, right side	•	•	•
Rearview mirrors, adjustable, el. heated	•	•	•
Reverse alarm	•	•	•
Reverse lights	•	•	•
Reversing warning light	•	•	•
Reverse warning light, strobe lightning	•	•	•
Warning beacon (flasher), LED automatic	•	٠	٠
Warning beacon (flasher), LED	•	•	•
Seatbelt indicator, external	•	•	•
Working lights, attachments, 1 LED	•	•	•
Warning beacon LED	•	•	•
Warning beacon LED automatic	•	•	•
LED Head Light	•	•	•
LED tail light	•	•	•
LED working lights, attachments LED working lights on cab, front and rear			•
LED working lights on cab, front, 2 alt. 4 LED			
lamps	•	•	•
LED working lights on cab, rear, 2 alt. 4 LED			
lamps	•	•	•
LED working lights, rear in grille, 2 LED lamps	•	•	•
LED working lights, front above head lamps, 2			
LED lamps			
LED work lights, side on cab, 4 LED lamps	•	•	•
LED light packages	•	•	•
Working lights an each hologon front and rear	•	•	•
Working lights on cab halogen, front and rear Working lights on cab halogen, rear	•	•	•
Co Pilot available	•	•	•
Rearview camera in Co pilot			
Max Boom height	•		
Can Bus Interface			
Delayed Engine Shutdown	•	•	•
Protective equipment			
Anti-theft device	•	•	•
Bellyguard front	•	•	•
Bellyguard rear	•	•	•
Boom cylinder hose and tube guards	•	•	•
Cab roof, heavy duty	•	•	•
Center hinge and rear frame guard	•	•	•
Corrosion protection, painting of machine	•	•	•
Cover plate front frame, heavy-duty	•	•	•
Cover plate, under cab	•	•	•
Cover plates rear frame	•	•	•
Guards for front headlights	•	•	•
Grease nipple guards	_	•	•
Guards for radiator grill		•	•
Guards for tail lights, heavy-duty	•	•	•
Wheel/axle seal guards Window guards, side and rear			
Windshield guard			
Trinusinela gadra			

·	L60H	L70H	L90H
External equipment			
Deleted front mudguards	•	•	•
Fire extinguisher	•	•	•
Bracket for fire extinguisher	•	•	•
Fire suppression system	•	•	•
Mudguards, full cover, rear for 80-series tires	•	•	•
Mudflap kit for mudguards, full cover for 80-series tires	•	•	•
Mudguards, full cover, rear and front/rear for 65-series tires	•	•	•
Mudflap kit for mudguards, full cover for 65-series tires	•	•	•
Footsteps front frame	•	•	•
Footsteps, right-hand side	•	•	•
Flexible rear step	•	•	•
Cab ladder, rubber suspended	•	•	•
Other equipment			
CareTrack, GSM/Satellite	•	•	•
CE-marking	•	•	•
Comfort Drive Control (CDC)	•	•	•
Comfort Drive Control (CDC) Electro-servo	•	•	•
Secondary steering	•	•	•
Counterweight, logging	•	•	•
Counterweight, signal painted, chevrons	•	•	•
Option for machines without dinitrol	•	•	•
Noise reduction kit, EU excluding decal	•	•	•
Sign, 50 km/h	•	•	•
Sign, slow moving vehicle	•	•	•

OPTIONAL EQUIPMENT					
	L60H	L70H	L90H		
Tires and Rims	•				
17.5R25	•	-	-		
20.5R25	•	•	•		
600/65R25	•	•	•		
650/65R25	_	-	•		
620/75R26 Agriculture application only	•	•	•		
750/65R26 Agriculture application only	•	•	•		
Attachments					
Buckets:	•	•	•		
Straight	•	•	•		
Spade nose	•	•	•		
High tipping	•	•	•		
Light material	•	•	•		
Grading	•	•	•		
Wear parts:	•	•	•		
Bolt-on edge	•	•	•		
Bolt-on or weld-on bucket teeth	•	•	•		
Segments	•	•	•		
Log grapples	•	•	•		
Fork equipment	•	•	•		
Material handling arm	•	•	•		
Snow blade	•	•	•		
Broom	•	•	•		
Sand spreading bucket	•	•	•		
Bale clamp	•	•	•		
Drum rotator	•	•	•		

# SELECTION OF VOLVO OPTIONAL EQUIPMENT

# External axle cooling (L70H, L90H)



Reversing camera with radar detect



Premium seat



**Comfort Drive Control** 



Light packages



Lock-up converter



Not all products are available in all markets. Under our policy of continuous improvement, we reserve the right to change specifications and design without prior notice. The illustrations do not necessarily show the standard version of the machine.

